


Bruker Walk Up Quick Guide



1) Create new data set. **click on**  **or type:** new↵ or edc↵



2) Insert Sample. sx ##

3) Tune Probe. **click on button**  **or type:** atma↵

4) Lock Solvent. **click on**  **or type:** lock↵ or e.g. lock cdcl3↵

5) Shim. **type:** topshim

6) Acquire data. **type:** rze

7) eject sample. **type:** sx ej